1

ROLLEI RPN PRINT NEUTRAL

ROLLEI RPN Print Neutral is the ideal paper developer for all standard tasks in the photo laboratory. It can be used universally and is equally suitable for PE/RC and FB papers. RPN produces a neutral image tone with deep blacks of consistent color and provides excellent fog resistance. Even with high dilution and high processing throughput, the good properties of this developer are fully retained. RPN is suitable for tray and machine processing.



Dilution 1+9:



900ml water + 100ml RPN =1I working solution Temp. 20°C / 68°F | Agitate regularly

AVA	ILABI	LE SI	ZES





250	ml

5.000 ml



Warning Contains Hydroquinone. Causes serious eye irritation. Sus-
pected of causing cancer. Harmful in contact with skin. Keep out of reach
of children. If in eyes: Rinse cautiously with water for several minutes.
Remove contact lenses, if present and easy to do. Continue rinsing. Wear
protective gloves/clothing, eye/face protection. If swallowed: Immedi-
ately call a poisoncenter or doctor/physician. If medical advice is needed,
have product container/label at hand.

APPLICATION	DILUTION	TIME (20°C/68°F)	CAPACITY (m²/l)
Normal Contrast	1 + 9	2 min.	1,8
Increased Contrast	1+6	2 min.	2 ½
Decreased Contrast	1 + 12	2 – 3 min.	1,4
Fast Development	1 + 4	1 – 1 ½ min.	3,6
Rapid Access Dev.	1 + 2	½ − ¾ min.	5
Processor, Machine	1 + 4	individual	individual

GENERAL NOTES:

CHEMISTRY | DILUTION | TIME | INTERVAL:

© 2019 | Hans O. Mahn GmbH & Co. KG | MACO PHOTO PRODUCTS | Brookstieg 4 | 22145 Stapelfeld | Germany | www.rolleianalog.com